



Einhell

PROFESSIONAL



Cordless Chain Saw

GP-LC 36/40 Li BL-Solo

Item No.: 4600050

Ident No.: 21013

Bar Code: 4006825678406

The Einhell Professional Cordless Chain Saw GP-LC 36/40 Li BL-Solo is a reliable assistant for felling medium to large trees. It is powered by the Einhell PurePOWER Brushless Motor for increased power and longer runtime. After online registration, the motor is covered by a 10-year warranty. The chainsaw features a 38 cm cutting length and is equipped with a high-quality OREGON chain with 1.3 mm thickness, 56 drive links, and 3/8" chain pitch. The saw chain is continuously and automatically lubricated from the 230 ml oil tank. For optimal protection, the batteries can be securely mounted on the side of the device. Delivery does not include battery and charger.

Features & Benefits

- Member of the Power X-Change family, 2x 18 V battery required
- Twin-Pack technology: 2x18V Power X-Change batteries - more power
- Brushless motor - more power and longer running time
- PurePOWER Brushless - 10-year motor warranty after registration
- Toolless chain tensioning and changing
- High-quality OREGON guide bar and sharp chain
- Perfectly balanced battery positioning
- Side positioning of the battery for optimal protection
- Automatic chain lubrication
- LED battery charge indicator for monitoring battery capacity
- Ergonomic handle with softgrip
- Sturdy stop claws made of metal
- Oil tank with gauge glass for automatic chain lubrication
- Kickback guard and instant chain brake
- Chain catcher for user protection
- Recommendation for optimal results: 2x 5.2 Ah battery or larger
- Delivery without battery and charger (available separately)



Technical Data

- | | |
|-----------------------|--------|
| - Sword length | 400 mm |
| - Max. cutting length | 38 cm |
| - Chain cutting speed | 19 m/s |
| - Oil tank capacity | 230 mL |



Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight (kg) | 4.76 kg |
| - Gross weight (kg) | 6.22 kg |
| - Dimensions single packaging | 275 x 520 x 245 mm |
| - Pieces per export carton | 2 Pieces |
| - Gross weight export carton | 12.94 kg |
| - Dimensions Export Carton | 540 x 510 x 290 mm |
| - Container quantity (20"/40"/40"HC) | 616 1232 1408 |



Available as special accessories



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



Spare bar 40cm 1,3
Chain Saw Accessory
Item No.: 4500156
Bar Code: 4006825548778
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
A1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



Spare Chain 40cm 1.3 56T 3/8
Chain Saw Accessory
Item No.: 4500367
Bar Code: 4006825681857
Einhell Accessory

Battery-Running-Times



cutting¹
(pieces)

One Battery for All

1.5 Ah	81
2.0 Ah	108
2.5 Ah	134
3.0 Ah	159
4.0 Ah	212
5.2 Ah	276
6.0 Ah	319
8.0 Ah	425

For best performance select a battery with at least 5.2 Ah

Test setup:

1) wood - scantling 70x70 mm