

Kameraablage / Camera Shelf


Art.-Nr./Ref. No. 4013 000114

Montageanleitung an den Kindermann DisplayLift 4013 0001xx

Mounting instructions on Kindermann DisplayLift 4013 0001xx

Lieferumfang / Scope of delivery

- 6x Inbusschraube M6x10
- 6x Allen screw M6x10
- 4x Scheibe Ø 8
- 4x Washer Ø 8
- 1x Kameraablage Teil 1
- 1x Camera shelf part 1
- 1x Kameraablage Teil 2
- 1x Camera shelf part 2



Kameraablage / Camera Shelf

Art.-Nr./Ref. No. 4013 000 114

Montageanleitung an das Kindermann DisplayShift 4031000 000

Mounting instructions on Kindermann DisplayShift 4031000 000

