





alpha**COOL**



AlphaCool
Core 1 CPU Block


EN	DE	FR	
Table of Contents		Table des matières	
Accessories	Zubehör	Accessoires	3
Preparation: Clean the CPU and apply Thermal Grease	Vorbereitung: CPU reinigen und Wärmeleitpaste auftragen	Préparation: Nettoyer l'UCT et appliquer la pâte thermique	4
AMD Mounting: Attach the bracket	AMD Montage: Halterung anbringen	AMD Montage: Fixer le support	5
AMD Mounting: Remove the protective film	AMD Montage: Schutzfolie entfernen	AMD Montage: Retirer le film de protection	5
AMD Mounting: Mount socket	AMD Montage: Sockel montieren	AMD Montage: Monter le socket	6
AMD Mounting: Mount cooler	AMD Montage: Kühler montieren	AMD Montage: Monter le refroidisseur	7
INTEL Mounting: Attach the bracket	INTEL Montage: Halterung anbringen	INTEL Montage: Fixer le support	8
INTEL Mounting: Remove the protective film	INTEL Montage: Schutzfolie entfernen	INTEL Montage: Retirer le film de protection	8
INTEL Mounting: Mount socket	INTEL Montage: Sockel montieren	INTEL Montage: Monter le socket	9
INTEL Mounting: Mount cooler	INTEL Montage: Kühler montieren	INTEL Montage: Monter le refroidisseur	10
Connect ARGB lighting	ARGB Beleuchtung anschließen	Connecter l'éclairage ARGB	11
Dimensions in millimeter (mm)	Abmessungen in Millimeter (mm)	Dimensions en millimètre (mm)	11



Safety instructions
Sicherheitshinweise
Avis de sécurité



Digital guide
Digitale Anleitung
Guide digital



EN

Accessories


DE

Zubehör

FR

Accessoires

A




1x
Thermal Grease

B




1x
Putty tool

C




1x
CPU Cooler

D




1x
CPU Brackets
AMD Set

E




4x
Threaded bolt
AMD

F




4x
Screw sleeve

G




1x
CPU Brackets
INTEL Set

H




1x
Core Backplate

I



4x
Threaded bolt
INTEL

J




4x
EVA Washer

K




1x
ARGB
Adapter


1





2



3









Hand tighten only.

Nur handfest anziehen.

Ne serrer qu'à la main.







The backplate (H) is only required for the Intel socket.


Die Backplate (H) wird nur für den Intel Sockel benötigt.


La plaque arrière (H) n'est nécessaire que pour le socket Intel.





Hand tighten only.

Nur handfest anziehen.

Ne serrer qu'à la main.







Need help?



Alphacool International GmbH
Marienberger Str. 1
D-38122 Braunschweig
Germany

Support: +49 (0) 531 28874-0
Fax: +49 (0) 531 28874 - 22
E-Mail: info@alphacool.com
<https://www.alphacool.com>

We care!