

HAVIT H630BT PRO ACTIVE NOISE CANCELLING WIRELESS HEADPHONES USER MANUAL	Product and Accessories: Headphone*1 3.5mm audio cable*1 Type-C Charging Cable*1 User Manual*1 Certificate of quality*1 1	Production structure 1. Mode button 2. Volume - 3. Volume + 4. Multi-function button(MFB) 5. AUX 6. LED indicator 7. Charging port 8. Charging indicator 2	Bluetooth Headphone power on/off 1. Power on: Long press the MFB to turn on; 2. Power off: Long press the MFB to turn off; Bluetooth connection Follow the steps(Please make sure that your phone is built-in Bluetooth function) 1. Turn on the headphone, the LED indicator flashes blue.While the LED indicator flashes alternately with blue and red, the headphone enters the pairing status. (Note: The headphone can automatically enter pairing status after power on if there is no re-connection. As the headphone can automatically reconnect with the last device that you had paired. To re-connect, you just need to turn it on.) 2. Activate the Bluetooth function and search for "HAVIT H630BT PRO" referring to your phone instructions.Click "HAVIT H630BT PRO" to connect. Dual devices connection Ensure two devices's Bluetooth open. 1. Enable A devices's Bluetooth pairing function and search for the "HAVIT H630BT PRO "to pair and connect.And disconnect 3	Bluetooth connection after successful connection.(Don't delete the pairing name in your device) 2. Connect the headphone with the B decive,and then turn on the Bluetooth pairing function of device A to connect the headphone. Music playing 1. Play/Pause: Short press the MFB 2. PREV: Long press "-"to switch the previous song 3. NEXT: Long press "+"to switch the next song 4. VOL + : Short press "+"to increase volume 5. VOL - : Short press "-" to decrease volume (Note:Since some mobile phones don't default to sync volume with headphones,please refer to the instructions of your phone and set on your phone.) ANC mode Switching Short press the Mode button to switch on/off ANC Mode. Wired mode: Dual 3.5mm Audio Cable connecting To Audio 1. Plug and play: Connecting the headphone to 4
a music player with the provided dual 3.5mm audio cable, the headphone can be used as wired headphone without starting. 2. In this mode, you can't use any function of the headphone, including play/pause music, volume adjustment, microphone and so on. Answering incoming calls Short press the MFB to answer incoming calls. (Note: Since some mobile phones default to answer calls via their own receiver, please refer to the instructions of your phone and set on your phone.) End the current call Short press the MFB to end the current call. Reject incoming calls Long press the MFB to reject a incoming call. Last number redial Double press the MFB to redial the last calling number. To charge the headphone 1. As product is built-in non-removable and rechargeable battery, please use the provided 5	charging cable to charge; 2. Fully charge the product before the first use.; 3. The LED indicator turns red when charging. After fully charged, the LED indicator will be steady blue. Notes a.Please choose the charger that is certified by the regular manufacturer. b.The battery performance may decrease as repeating charging and using the product. It's a normal phenomenon for all rechargeable batteries. SAFETY TIPS 1. Don't expose the earbuds to liquids, moisture or humidity as they have electronics and battery inside. 2. Don't disassemble your earbuds. There are no user serviceable parts inside it. 3. Don't drop the earbuds and keep them away from sharp objects such as keys in your pockets. 4. Charge your earbuds below 5V/A charger. 5. Don't expose the earbuds to extremely high or low temperature as this may damage the 6	battery or even deform the plastic parts. 6. Listen to the music at high volume is harmful to your ears. 7. Don't throw the earbuds in a fire to dispose it otherwise inside battery may explore. FCC ID: 2AIG-H630BTPRO FCC WARNING FCC STATEMENT 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide 7	reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. RF WARNING STATEMENT The device has been evaluated to meet general RF exposure requirement. The device can be used 8	in portable exposure condition without restriction. BATTERIES: A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the light. 1) Replacement of a battery with an incorrect type that can defeat a safeguard. 2) Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion. 3) Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage off lammable liquid or gas. 4) A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas. www.havitsmart.com 9